

Before you start, review directions completely.  
If your vehicle is not pre-wired for external lighting, you may need the following:

- In-line Fuse Holder (SPXATC16 or similar)
  - 3 Amp Fuse
  - 2 Strand Primary Wire
  - Wire Connectors / Solder
  - Wire Cover
  - Zip-Ties
- Optional:**
- Switch
  - Relay


## MOUNTING THE LED PODS

1. Determine a location for the RGB module There are 4, 10 ft extensions that can be used if necessary.
2. For correct light pattern flow, mount each pod with the female connector end facing the front of the vehicle.


**NOTE: The correct light flow starts from the module to each rock light.**

**Avoid mounting the module in locations that get extremely hot or wet.**

3. Mount the LED pods using the Flat or Curved Rubber Mounting pads. Lights should be mounted in a location where they will not come in contact with suspension, tires or road surface.




Pass-through both male and female connectors through the center hole




4. Route and connect the light cables to the RGB module in a daisy chain connection pattern making sure to avoid interference with suspension, exhaust or any moving parts .

## WHAT'S INCLUDED


- 4 x SMD LED Pods
- 4 x Pod Extension Cables (10ft)
- 4 x Flat Rubber Mounting Pads
- 4 x Curved Rubber Mounting Pads
- 1 x Bluetooth RGB Control Module with connection for **HEIGH10**
- 1 x RF Remote Control
- 8 x Mounting Screws




Back of mounting pad has 3 cable routing options



Curved Mounting Pad for installation on tubular frame



Flat Mounting Pad



## 8 ROCK LIGHT DYNAMIC RGB LED KIT

Before you start, review directions completely.  
If your vehicle is not pre-wired for external lighting, you may need the following:

- In-line Fuse Holder (SPXATC16 or similar)
  - 3 Amp Fuse
  - 2 Strand Primary Wire
  - Wire Connectors / Solder
  - Wire Cover
  - Zip-Ties
- Optional:**
- Switch
  - Relay

### WHAT'S INCLUDED

- 8 x SMD LED Pods
- 8 x Pod Extension Cables (10ft)
- 8 x Flat Rubber Mounting Pads
- 8 x Curved Rubber Mounting Pads
- 1 x Bluetooth RGB Control Module with connection for **HEIGH10**
- 1 x RF Remote Control
- 16 x Mounting Screws


### MOUNTING THE LED PODS

1. Determine a location for the RGB module. There are eight 10 ft extensions that can be used if necessary.
2. For correct light pattern flow, mount each pod with the female connector end facing the front of the vehicle.

**NOTE: The correct light flow starts from the module to each rock light.**

**Avoid mounting the module in locations that get extremely hot or wet.**


3. Mount the LED pods using the Flat or Curved Rubber Mounting pads. Lights should be mounted in a location where they will not come in contact with suspension, tires or road surface.




Pass-through both male and female connectors through the center hole

4. Route and connect the light cables to the RGB module in a daisy chain connection pattern making sure to avoid interference with suspension, exhaust or any moving parts.



Back of mounting pad has 3 cable routing options



Curved Mounting Pad for installation on tubular frame



Flat Mounting Pad



## 8 ROCK LIGHT KIT CONNECTED WITH LED STRIP LIGHTS AND LED WHIP LIGHTS

Each Rock Light Pod has an Input connection and an output connection allowing you to connect other products to the same control module

Here is a diagram showing how to connect the SPXDK8 with 2 SPXD5 (Light Strips) and ending in a SPXDW4 (LED Whips)

Female Connector  
(Input ←)



Male Connector  
(Output →)



**SPXD5**


*Optional LED strip lights  
sold separately*

**SPXD5**

*Optional LED strip lights  
sold separately*

**SPXDW4**

*Optional Whip LED Lights  
sold separately*





## ROCK LIGHT KIT POWER WIRING DIAGRAM

### WIRING DIAGRAMS


**Diagram 1:** Wiring direct to power and using an App to turn on/off. Must add 3 AMP fuse on RED 12V+ wire.

**Diagram 2:** Wiring with a switch. You can add a new dedicated switch or use an existing light switch that outputs 12V+ when ON. You will need to add a 3 AMP fuse on the RED 12V+ wire and also requires a 12V relay. Note: When wired to a switch, the RGB controller will default to last mode/color used. No need to access the app.



**HEIGH10 connection:** Connect the Sirius XM harness to the HEIGH10, then connect the 4 pin male connector of the LED module to the female connector of the HEIGH10 Sirius XM harness. If your HEIGH10 is missing the harness or has the wrong connector you will need to purchase the optional harness (**SE-SXMHAR**)

**NOTE:** Lighting module will still need separate power and ground when connecting SE-SXMHAR




### GET THE APP

Scan the QR Code, or visit Google Play or iTunes to download the *Stinger Lighting* app. Once the app is installed, power up the RGB Module and open the app. The module should auto-connect and be listed in the device list. And Jon says Let There Be Light.



SCAN for Apple iOS and Android App

- Device Group List
- Choose LED color
- Choose LED patterns and colors
- Make custom LED color and patterns
- Play lights from internal audio file, or microphone
- App settings



Stinger Lighting App

### LIMITED WARRANTY:

Stinger warrants this product to be free of defects in materials and workmanship for a period of one (1) years from the original date of purchase. This warranty is not transferable and applies only to the original purchaser from an authorized Stinger dealer in the United States of America only. Should service be necessary under this warranty for any reason due to manufacturing defect or malfunction, Stinger will (at its discretion), repair or replace the defective product with new or re-manufactured product at no charge. Damage caused by the following is not covered under warranty: accident, misuse, abuse, product modification or neglect, failure to follow installation instructions, unauthorized repair attempts, misrepresentations by the seller. This warranty does not cover incidental or consequential damages and does not cover the cost of removing or reinstalling the unit(s). Cosmetic damage due to accident or normal wear and tear is not covered under warranty.

### INTERNATIONAL WARRANTIES:

Products purchased outside the United States of America are covered only by that country's Authorized Stinger reseller and not by Stinger. Consumers needing service or warranty information for these products must contact that country's reseller for information.

Stinger is a Power Brand of AAMP Global  
15500 Lightwave, Clearwater, Florida 33760  
P: 888-228-5560

support@stingerelectronics.com  
www.stingerelectronics.com  
© 2019 AAMP Global